

# BMW E30-F INSTALLATION INSTRUCTION

Installation instruction  
1. Please remove SPINDLES from original shock

